

**FUEL SYSTEM**

POS.	CODE	DESCRIPTION	Qty
1	9043.037	FUEL TANK CAP	1
2	1200.015	O ring 137 for filler oil cap	1
3	8103.054	fuel tank 1.5,2	1
4	9135.011	cushion	2
5	<----->	bleeding pipe	0
6	9571.204	bleeding pipe mm 330	1
7	<----->	union bolt	0
11	4896.249	NOZZLE-HOLDER ASS.Y	1
11	6615.084	nozzle-holder	1
12	3790.070	flange	1
13	7301.155	union	1
14	8335.193	spacer	0
16	<----->	spring	0
17	8010.008	seat	1
18	<----->	cup	0
22	3240.021	nut M 8	2
23	1770.031	bolt M 8 X 1,25 X 50	2
24	5400.046	rubber sheathing	1
25	3617.016	clamp	1
26	9370.010	high press.pipe	1
27	<----->	seat	0
31	3240.163	nut M 8	2
32	<----->	gasket - no longer available	0
33	6780.164	stud M 8 X 55	2
34	6531.425	nozzle	1
37	4130.115	locking nut	1
39	<----->	superseded by Pos. E 11 (4896.249)	0
41	4670.005	copper gasket 0,50	1
41	4670.006	copper gasket 1,00	1
42	<----->	stud	0
55	5575.006	spring	1
56	3930.019	cup	1
57	1200.268	rubber oil seal	1
58	2175.009	fuel filter cartridge	1
58	3730.015	FUEL FILTER	1
59	4490.017	gasket	1
60	4430.071	gasket	1
61	<----->	copper gasket diam. 8,2X12X1,5	0
63	3240.163	nut M 8	2
65	3525.092	spacer	2
66	1770.007	bolt M 8 X 1,25 X 30	2
66	1770.031	bolt M 8 X 1,25 X 50	2
67	7265.008	connection	1
68	1200.031	rubber oil seal	1
69	8335.029	washer seal	1
70	7470.003	filler	1
71	9672.013	delivery valve	1
72	9732.074	screw M 8 X 20	3
74	6578.013	injection plunger (for injection pump 6590.033 - no longer avai	1
74	6578.205	plunger for rewind starting for injection pump 6590.263	1
75	3630.008	clamp	1
76	<----->	spring retainer bottom - see Pos. E 91	0
77	9375.274	hose from gear side tank to inj.pump (mm 142)	1

Group: 3LD
Engine: 3LD 510/L Drawing: E

FUEL SYSTEM

POS.	CODE	DESCRIPTION	Qty
78	5625.002	spring	1
79	7980.020	cup	1
80	4850.009	guide	1
81	7215.017	tappet	1
82	«-----»	no longer available	0
84	6230.068	pin	1
85	5755.034	valve spring	1
86	4760.015	valve gasket	1
87	4670.060	copper gasket diam.12	2
88	1901.171	deaeration plug	1
89	4775.196	gasket	1
90	1901.031	union bolt M 12	1
91	6590.263	injection pump	1
92	«-----»	no longer available	0
94	1580.016	bushing	1
95	2800.003	cotter pin	1
96	771R.001	washer diam. 5,3	1
97	6230.069	pin	1
98	«-----»	ring	0
101	9375.032	fuel hose mm 336	1
105	3730.036	FUEL FILTER	1
106	2605.033	filter cover	1
107	1202.052	rubber oil seal	1
108	9043.025	FUEL TANK CAP	1
109	4650.056	gasket	1
110	1760.162	bolt	1
111	4580.001	gasket 0,10	1
111	4580.008	gasket 0,50	1
111	4580.012	gasket 0,30	1
111	4580.039	gasket 0,05	1
112	1240.013	snap ring	1
113	8102.093	fuel tank 1.5,2	1
113a	8102.091	fuel tank 1.7,5	1
114	«-----»	bolt M 8 X 1,25 X 55	0
116	4330.025	inj.pump rocker arm	1
117	«-----»	inj.rocker arm shaft	0
118	6045.073	rocker shaft	1
121	9373.043	fuel hose(mm 635)	1
122	2175.045	fuel filter cartridge	1
123	4670.061	copper gasket diam.14	4
124	1901.032	union bolt M 14	2
129	9375.856	fuel hose mm 1030	1
132	4670.059	copper gasket diam.10	2

